ADI 0025-24V-J



# 24V ALTOS 2<sup>™</sup> System Monitor

## **INSTALLATION AND OPERATING INSTRUCTIONS**

**Carefully Read These Instructions Before Operating** 

Controls Corporation of America 1501 Harpers Road • Virginia Beach, VA 23454 Telephone 1-800-225-0473 or 757-422-8330 • Fax 757-422-3125 www.concoa.com

June 2024 Revision J

### SAFETY



BASIC SAFETY PRECAUTIONS MUST BE FOLLOWED TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK OR INJURY.

- While the 24V Altos 2<sup>™</sup> is dust and moisture resistant, it is NOT water-proof or completely sealed. It should be installed where it will not be subjected to rain or high concentrations of dust. Never pour or spray liquids directly onto the product.
- Install the 24V Altos 2<sup>TM</sup> where the ambient temperature range is between 0°F and 140°F.
- THIS PRODUCT IS NOT INTENDED FOR USE IN EXPLOSIVE ENVIRONMENTS.
- DO NOT INSTALL THIS PRODUCT IN ANY HAZARDOUS ENVIRONMENT.
- If product appears damaged in any way, do not use and request service from CONCOA.

### USER RESPONSIBILITY

Service to this product should only be performed by CONCOA or an authorized CONCOA agent. Requests for service may be made through CONCOA CUSTOMER SERVICE at 1-800-225-0473. Written requests may be made using CONCOA's FAX number at 1-757-422-3125 or CONCOA's E-MAIL at info@concoa.com

CONCOA accepts no responsibility for damage or injury if this product is modified in any way.

CONCOA assumes/accepts no liability or responsibility for damage to individuals or equipment that may occur when using this product

Index	
DESCRIPTION OF PRODUCT	
POWER REQUIREMENTS	
ALARM OUTPUT RELAY SPECIFICATIONS:	2
UNDERSTANDING ALARM OPERATION	3
MOUNTING REQUIREMENTS	4
INSTALLATION INSTRUCTIONS	5
CONNECTING EXTERNAL INPUT DEVICES TO THE 24V ALTOS 2™	5
CIRCUIT BOARD STYLES	5
Figure 3 – Circuit Board Terminal Block Locations	6
Table 1 – Terminal Block & Switch Descriptions	7
Wiring Instructions for Specific CONCOA Products	
Table 2 – Cable Information	
CONNECTING ALARM OUTPUTS	
MUTING AUDIBLE ALARM	
Wiring Customer Supplied Power	
CONFIGURATION USING THE LCD SCREEN	
SETTINGS MENU	
CHANNEL SETTINGS	
Input/Alarm Mode	30
Alarm Set Point	
Units of Measure	
ALARM SETTINGS	
Alarm Delay	
Blink When Both In Alarm	
SYSTEM SETTINGS	35
Set Channel Offset	35
Set Channel Max	
Deadband	
Audible Mode	39
Power Save Mode	40
Keypad Lockout	
Contrast	
Test Mode	
Reset	
About	
TROUBLESHOOTING	
WARRANTY INFORMATION	45
CE Declaration of Conformity for CE Approved Models	

#### Index

## **DESCRIPTION OF PRODUCT**

The CONCOA 24V Altos 2<sup>TM</sup> system monitor reports the status of up to 2 individual points of observation. Ideal for monitoring automatic switchovers and other fail-safe gas delivery installations with pressure switch or transducer pressure monitoring capability. The reading for 4-20mA input signals or contact closure status for pressure switches or dry contacts will be displayed locally on a 2.9" LCD screen for up to 2 channels. The statuses of all inputs are also displayed locally with high visibility multicolor LEDs that turn red when an input exits its normal condition. Additionally, status may be accessed through three dry contact relay outputs, one for each input channel and a master alarm.

#### POWER REQUIREMENTS

#### **CONCOA Supplied Power:**

CONCOA provides a universal 120/240 VAC 50/60Hz, 19W external power adapter.

#### Customer Supplied Power:

Internally, the Altos2 needs a 24 VDC, 19W power source via a cable with 3/16" Quick Connect Receptacle termination, "Ultra-Fast" style, fully insulated.

#### ALARM OUTPUT RELAY SPECIFICATIONS:

Contacts: Normally Open/ Normally Closed Dry Contact

Contact Rating: 24 volts DC @ 1 amp Max.

#### UNDERSTANDING ALARM OPERATION



Figure 1 shows the location of the various inputs, outputs, and indicators for the 24V Altos 2<sup>TM</sup>. The 24V Altos 2<sup>TM</sup> has a universal power supply.

Input signals coming from external devices are connected to the 24V Altos 2<sup>TM</sup> via individual wires through a 1/2" conduit connection in the bottom of the enclosure to a terminal strip.

The 24V Altos 2<sup>TM</sup> provides output relay signals to indicate the state of channel 1, 2, and the master alarm. The master alarm is engaged when either channel is in alarm with signals brought out through terminal connectors consisting of 3 terminal blocks. Each terminal block contains a common voltage input, a normally-closed contact, and a normally-open contact. Figure 1 shows a view of the front panel which is laid out with two status lights representing channels 1 and 2. The indicator lights are bi-colored LEDs so that the same light can be turned ON as either a green indicator or a red indicator. A green LED indicates a normal condition. A red LED indicates that both channels are in alarm.

On the left side of the front panel, a speaker is used to provide an audible indication of an alarm condition. The alarm silence button in the upper right portion of the front panel allows the operator to silence the audible alarm even while an alarm condition still exists.

In the center of the front panel is a 2.9" diagonal LCD screen used for displaying channel 1 and 2 status as well as system configuration menus. On the right side of the screen are four directional arrows used for navigating the configuration menu.

The 24V Altos 2<sup>™</sup> allows for a 4-20mA input signal from any device (e.g., transducer, scale, etc.) or a contact closure input (typical pressure switch) for channel monitoring. The channel configuration is selectable via the system menu.

The 4-20mA inputs are accessed via a terminal block containing the +24vdc supply line and the signal return for each channel. The channel pressure is displayed on the LCD screen and, depending on the channel alarm configuration and set point, the channel LED with either be green (normal state) or red (alarm state).

The contact closure inputs are also accessed via a terminal block containing a +24vdc supply line and a signal return for each channel. The 24V Altos  $2^{TM}$  can use normally closed (N.C.) or normally open (N.O.) contact signals from the external inputs to determine the state of the alarms. The normal conditions of these alarms are customizable via the configuration menu.

If there are no alarm conditions, the 24V Altos 2<sup>TM</sup> will turn on the green indicator next to the status being monitored. When an alarm condition occurs, the color of the indicator next to its status changes from green to red. At the same time, the audible buzzer in the 24V Altos 2<sup>TM</sup>, if enabled, will begin to sound. The LCD screen will display the current channel pressure or whether the contact is open or closed depending on the channel's configuration. The set of contacts representing this alarm condition will alarm in the relay output section of the 24V Altos 2<sup>TM</sup>.

#### **MOUNTING REQUIREMENTS**



## **INSTALLATION INSTRUCTIONS**

After mounting the 24V Altos 2<sup>TM</sup> to the wall, wire any monitored devices through the conduit connections and to the input terminal blocks (see Figures 3-17, Table 1). If using the relay output of the 24V Altos 2<sup>TM</sup> to connect to another alarm or system, attach wires to the relay output terminal blocks (see Figure 3, Table 1).

Turn 24V Altos 2<sup>™</sup> on by plugging the unit directly into a wall outlet and turning the power switch on the left side of the unit to the on position. The system may be tested once it is connected to an external device by tripping the external alarm, causing the corresponding input LED to turn red.

## CONNECTING EXTERNAL INPUT DEVICES TO THE 24V ALTOS 2™

The 24V Altos 2<sup>TM</sup> is designed to interface with up to 2 external 4-20 mA input signals (transducers by default) or any dry contact inputs depending on the channel configuration. The external device wires (+24Vdc out, signal in) are brought in through a conduit connector on the left side of the box and connected to terminal blocks on the left hand side of the circuit board. Figures 3-17 and Table 1 outline how to connect various CONCOA products to the 24V Altos 2<sup>TM</sup>.

The recommended cable for this assembly is 18-26 AWG wire (Alpha # 1176C or equivalent). The length of each cable should be limited to 500 feet for pressure transducers and 1500 feet for dry contact inputs.

After cutting the cable to length, remove the outer jacket to expose approximately 3/4 inch of the internal conductors on both sides of the cable. Strip away 1/4-inch of the insulation on each of the conductors, unscrew the terminal block, insert wire, and tighten screw. Test to ensure the wire does not pull out of the connector.

Table 2 shows common wire part numbers that are available to connect to various CONCOA devices. Contact CONCOA for details.

## **CIRCUIT BOARD STYLES**

Your 24V Altos 2<sup>TM</sup> will have one of the following two styles of circuit board. The style will be indicated by "CV1" or "CE" printed on the product nameplate and box label:

Circuit Board Style A - CV1 Models:



## Figure 3 – Circuit Board Terminal Block Locations TERMINAL BLOCKS & DIPS SWITCHES, CIRCUIT BOARD STYLE A (CV1 Models)



TERMINAL BLOCKS & DIPS SWITCHES, CIRCUIT BOARD STYLE B (CE Approved Models)



## Table 1 – Terminal Block & Switch Descriptions

CIRCUIT BOARD STYLE A - CV1 MODELS		CIRCUIT BOARD STYLE B - CE APPROVED MODELS		
Inputs, Digital		Inputs, Digital		
Terminal	Function	Terminal	Function	
J19 "IN1"	Channel 1 Pressure Switch Signal Return	J1-1	Channel 1 Pressure Switch Signal Return	
J19 "+24V" Top	Channel 1 Pressure Switch +24V Supply	J1-2	Channel 1 Pressure Switch +24V Supply	
J19 "IN2"	Channel 2 Pressure Switch Signal Return	J1-3	Channel 2 Pressure Switch Signal Return	
J19 "+24V" Bottor	nChannel 1 Pressure Switch +24V Supply	J1-4	Channel 1 Pressure Switch +24V Supply	
Inputs, Analog		Inputs, Analog		
Terminal	Function	Terminal	Function	
J8 "XDCR A -"	Channel 1 Transducer Signal Return (Normally Left Side)	J4-1	Channel 1 Transducer Signal Return (Normally Left Side)	
J8 "XDCR A +"	Channel 1 Transducer +24V Supply (Normally Left Side)	J4-2	Channel 1 Transducer +24V Supply (Normally Left Side)	
J13 "XDCR B -"	Channel 2 Transducer Signal Return (Normally Right Side)	J4-3	Channel 2 Transducer Signal Return (Normally Right Side)	
J13 "XDCR B +"	Channel 2 Transducer +24V Supply (Normally Right Side)	J4-4	Channel 2 Transducer +24V Supply (Normally Right Side)	
Outputs, Digital		Outputs, Digital		
J20 "GND"	System Ground	J2-1	Channel 1 Digital Output	
J20 "OUT 1"	Channel 1 Digital Output	J2-2	Channel 2 Digital Output	
J20 "OUT 2"	Channel 2 Digital Output	J2-3	System Ground	
Outputs, Channel 1		Outputs, Channel 1		
Terminal	Function	Terminal	Function	
J4 "NC"	Channel 1 Normally Closed Relay Output	J7-1	Channel 1 Normally Closed Relay Output	
J4 "COM"	Channel 1 Relay Common	J7-2	Channel 1 Relay Common	
J4 "NO"	Channel 1 Normally Open Relay Output	J7-3	Channel 1 Normally Open Relay Output	
Outputs, Channel 2			Outputs, Channel 2	
Terminal	Function	Terminal	Function	
J3 "NC"	Channel 2 Normally Closed Relay Output	J6-1	Channel 2 Normally Closed Relay Output	
J3 "COM"	Channel 2 Relay Common	J6-2	Channel 2 Relay Common	
J3 "NO"	Channel 2 Normally Open Relay Output	J6-3	Channel 2 Normally Open Relay Output	
Outputs, Master			Outputs, Master	
Terminal	Function	Terminal	Function	
J6 "NC"	Master Normally Closed Relay Output	J5-1	Master Normally Closed Relay Output	
J6 "COM"	Master Relay Common	J5-2	Master Relay Common	
J6 "NO"	Master Normally Open Relay Output	J5-3	Master Normally Open Relay Output	
DIP Switches			DIP Switches	
Switch	Function	Switch	Function	
SW5-1	ON to Enable Audible Alarm	SW1-4	ON to Enable Audible Alarm	
SW5-2	ON to Enable Keypad	SW1-3	OFF to Enable Keypad	
SW5-3	Reserved	SW1-2	Reserved	
SW5-4	Reserved	SW1-1	Reserved	
SW5-5	Reserved			
SW5-6	Reserved			

## Wiring Instructions for Specific CONCOA Products

Figures 4, 5 & 6 for Circuit Board Style A ("CV1")







Figure 7 for Circuit Board Style A ("CV1")





Dual Regulator Switchovers with Standard Transducers









\* See Table 2 for cable information.

OUT2





#### Dual Regulator Switchovers with Pressure Switch Gauges See Table 2 for Pressure Switch Gauge Left Cables are Provided cable information. Hooked-Up Through Pressure Wire 1 Switch Left Side Bracket Slot Left Ш Gauge Side Cable to Wire 2 Alarm or Intrinsic Wire 3 Safety Right Side Barriers Right Wire 4 Pressure Switch Gauge 27 Remove Terminal Block Cover t PUSH то INSERT WIRE Route Cable Through Right Side Bracket Slot and Out to Alarm or Intrinsic Safety Barriers. Reassemble the Terminal Block Cover. For Models without Intrinsic Safety Barriers: J2 2 2 3 4 3 $\oplus \oplus \oplus$ 4 Cable from 8 ш Switchover Wire 2 Wire 1 Wire 4 Wire 3 For Models with Intrinsic Safety Barriers: Wire 5 to Ground Block Wire 1 to B1 "1" Wire 2 to B1 "2" J1 J2 Wire 3 to B2 "1" 2 3 4 2 3 1 Customer to provide ground Wire 4 to B2 "2" **\*\*\*** ◍◍ conn. to the ground block. + + n \* See Table 2 for cable B õ





If Present: Cut off White Wire or Wires

\*\* Product comes with 25ft

long transducer cables.

Bank

Cable

#### Figure 10 for Circuit Board Style B ("CE")



## AutoSwitches with Pressure Switch Gauges,



#### AutoSwitches with Transducers, Without Intrinsic Safety Barriers



#### Figure 11 for Circuit Board Style A ("CV1")

Circuit Board Style A (CV1)

#### DO NOT USE ALTOS 2 ALARM WITH INTRINSIC SAFETY BARRIERS ON AUTOSWITCHES THAT HAVE PRESSURE SWITCH GAUGES. Intrinsic Safety Barriers Require Use of AutoSwitch Models with Transducers.

#### AutoSwitches with Transducers, With Intrinsic Safety Barriers





#### DO NOT USE ALTOS 2 ALARM WITH INTRINSIC SAFETY BARRIERS ON AUTOSWITCHES THAT HAVE PRESSURE SWITCH GAUGES. Intrinsic Safety Barriers Require Use of AutoSwitch Models with Transducers.

#### AutoSwitches with Transducers, With Intrinsic Safety Barriers





#### 539 / 640 / 641 Series IntelliSwitches



#### Figure 12 for Circuit Board Style B ("CE")









#### 538 / 544 / 642 / 643 Series IntelliSwitch IIs



#### Figure 13 for Circuit Board Style B ("CE")



#### 538 / 544 / 642 / 643 Series IntelliSwitch IIs





### 542 Series High Flow Backup System



#### Figure 14 for Circuit Board Style B ("CE")



#### 542 Series High Flow Backup System



Figure 15 for Circuit Board Style A ("CV1")





#### Figure 15 for Circuit Board Style B ("CE")









## Table 2 – Cable Information

CABLES				
CONCOA Cable Ass'y Part No.	Usage			
<b>5295320-L</b> ("L"= length - contact CONCOA for options) 4-Pin Circular Connector x 4 Bare Wires (Red, Green, White, Black)	542 Series High Flow Backup System			
<b>5295342-L</b> ("L"= length - contact CONCOA for options) 6-Pin Circular Connector x 6 Bare Wires (Blue, Green, Red, Orange, White, Black)	IntelliSwitch 1			
<b>5295349-L</b> ("L"= length - contact CONCOA for options) 8-Pin Circular Connector x 7 Bare Wires (Blue, Red, Orange, Black, White, Green, Brown)	577 Series CryoWiz™			
<b>5295360-01-L</b> ("L"= length - contact CONCOA for options) Packard Connector x 2 Bare Wires (Black, Red)	All CONCOA Products with Standard Transducer(s) (Not Applicable for Products with Intrinsically Safe Transducer(s))			
<ul> <li>The following products will be provided with a 25ft long cable appropriate for your application (customer to cut and strip wires and select usage for wire colors):</li> <li>Products with a pressure switch gauge/gauges and a terminal block wiring arrangement.</li> <li>Products with intrinsic safety barriers - cable to hook up barriers to remote alarm.</li> <li>Products such as the IntelliSwitch II that have only a terminal block for alarm hookup.</li> </ul>				
Available Cables: 5296002-25-001 = 25ft Long 2 wire cable (wire colors: black, red) 5296002-100-001 = 100ft Long 2 wire cable (wire colors: black, red)				
5296003-25-001 = 25ft Long 3 wire cable (wire colors: black, red, white) 5296003-100-001 = 100ft Long 3 wire cable (wire colors: black, red, white)				
5296004-25-001 = 25ft Long 4 wire cable (wire colors: black, red, white, green) 5296004-100-001 = 100ft Long 4 wire cable (wire colors: black, red, white, green)				
5296006-25-001 = 25ft Long 6 wire cable (wire colors: black, red, white, green, brown, blue) 5296006-100-001 = 100ft Long 6 wire cable (wire colors: black, red, white, green, brown, blue)				
5296008-25-001 = 25ft Long 8 wire cable (wire colors: black, red, white, green, brown, blue, orange, yellow) 5296008-100-001 = 100ft Long 8 wirecable (wire colors: black, red, white, green, brown, blue, orange, yellow)				

## **CONNECTING ALARM OUTPUTS**

The 24V Altos 2<sup>TM</sup> provides output signals corresponding to the alarm conditions that it senses, presented through relay contacts, and brought out to terminal connectors on the right hand side of the circuit board connector at the bottom of the alarm.. Route the output relay signals from the 24V Altos 2<sup>TM</sup> terminal strip via individual wires through the 1/2" conduit opening on the bottom of the enclosure. A total of three relay output terminal strips are on the circuit board; one for each channel and a master alarm signal. Each terminal strip contains the independent common input signal, a normally closed output, and a normally open output. (See Figure 3 for terminal strip locations.)

If using the recommended Normally Open side of the contact then an alarm or a loss of power or an accidently cut alarm wire will result in an open circuit and all three conditions will look the same to a downstream device.

The recommended cable for making an output cable assembly is 18-26 AWG. The length of each cable should be limited to 1500 feet.

After cutting the cable to length, remove the outer jacket to expose approximately 3/4 inch of the internal conductors on both sides of the cable. Strip away 1/4-inch of the insulation on each of the conductors, unscrew the terminal block, insert wire, and tighten screw. Test to ensure the wire does not pull out of the connector.

#### **MUTING AUDIBLE ALARM**

It is sometimes desirable to silence the audible alarm on the 24V Altos 2<sup>TM</sup>. This can be accomplished in one of two ways.

- 1) Pressing the alarm silence button on the top right hand side of the front panel will temporarily silence the alarm. In this mode, the audible alarm will automatically sound on the next asserted alarm
- 2) To permanently silence the alarm, power down the unit, open the front cover, and flip SW6-4 off (open) (See Figure 32.).

### Wiring Customer Supplied Power

If the customer is supplying their own power adapter, follow these requirements:

- The Altos2 requires a 24V 19W power source.
- Ground is attached directly to the Altos2 PCB ground plug Terminal TM2. 24V power is attached to the open terminal of the power switch in the Altos2 enclosure. Both connections are made with 3/16" Quick Connect Receptacles, "Ultra-Fast" style, fully insulated.



### **CONFIGURATION USING THE LCD SCREEN**

The 24V Altos 2<sup>TM</sup> is equipped with an LCD screen for displaying system status and configuration of the system. The 24V Altos 2<sup>TM</sup> LCD screen displays system status by default.



The 24V Altos  $2^{TM}$  Settings Menu is also displayed via the LCD screen. Pressing any navigation button on the front right of the enclosure (Figures 1 + 18) when the status screen is displayed will enter the Settings Menu.

Figure 19



The up and down keys allow the user to navigate the menu selections. To enter a menu selection, press right/enter when the selection is highlighted. To go back a level, press the left/back key. To disable the navigation buttons, power down the unit, open the front cover and flip SW1-4 on (closed) (See Figure 3.). Pressing the navigation buttons when the keypad is locked will cause the 24V Altos 2<sup>TM</sup> to display a keypad lock out warning for a couple of seconds before returning to the display screen.

#### **SETTINGS MENU**

The 24V Altos 2<sup>TM</sup> Settings Menu is divided into four sections: Channel1, Channel2, Alarm, and System. Pressing right/enter when the selection is highlighted enters the submenu.



- "Channel 1" and "Channel 2" = Input configuration settings for channels 1 and 2 respectively.
- "Alarm" = Global alarm configuration settings.
- "System" = System configuration settings.

## **CHANNEL SETTINGS**

The Channel Settings Menus "Channel 1 " and "Channel 2" contain three settings for each channel: Input/Alarm Mode, Alarm Set Point, and Units of Measure



Figure 21

#### Input/Alarm Mode

Input/Alarm mode configures the specified channel input for the transducer (or other 4-20mA signal) or contact closure, or disables the input.

sabled

- Transducer/Over Configures the specified channel to use the transducer or other 4-20mA signal input and causes the channel to alarm when the measured pressure rises above the alarm set point (see Alarm Set Point Section).
- Transducer/Under (DEFAULT) Configures the specified channel to use the transducer or other 4-20mA signal input and causes the channel to alarm when the measured pressure falls below the alarm set point (see Alarm Set Point section).
- Switch/Closed Configures the specified channel to use the contact closure input and causes the channel to alarm when the contact closes.
- Switch/Open Configures the specified channel to use the contact closure input and causes the channel to alarm when the contact opens.
- Input Disabled Disables the input so that the specified channel will not alarm, the corresponding LED turns off, and the LCD screen displays five dashes.

#### **Alarm Set Point**

Alarm Set Point determines the value at which the 24V Altos 2<sup>™</sup> will alarm when it is configured for Transducer (or other 4-20mA signal)/Over or Transducer (or other 4-20mA signal)/Under mode.

Figure 23 = Setpoint Value = 6000 PSIG Value = Min PSIG - 0 PSIG

Pressing up or down on a particular digit will modify only the selected digit. To navigate between digits, press left or right. To save the selected setting, navigate to the far right digit and press right again. The 24V Altos 2<sup>TM</sup> will not allow the user to select a value outside the maximum and minimum values displayed. The default value for this setting is 500 PSI.

#### **Units of Measure**

Units of Measure determines BAR, PSI, kPa, Lb, or Kg. 24V Altos 2<sup>TM</sup> will display the selection for the specified channel. The default setting is PSI.



## ALARM SETTINGS

The Alarm Configuration menu contains two global alarm choices: Alarm Delay and Blink.



#### **Alarm Delay**

Alarm Delay specifies the number of minutes after an alarm condition is detected for the 24V Altos  $2^{TM}$  to display an alarm condition.



Pressing up or down on a particular digit will modify only the selected digit. To navigate between digits press left or right. To save the selected setting, navigate to the far right digit and press right again. The 24V Altos 2<sup>TM</sup> will not allow the user to select a value outside the maximum and minimum values displayed. The default value for this setting is 0 minutes.

#### **Blink When Both In Alarm**

Blink When Both in Alarm causes the red alarm LEDs to blink when both channels are in alarm. The default setting is OFF.


## SYSTEM SETTINGS

The System Configuration menus contain twelve settings: Set Ch1 Offset, Set Ch2 Offset, Set Ch1 Max, Set Ch2 Max, Deadband Ch1, Deadband Ch2, Audible Mode, Power Save Mode, Keypad Lockout, Test Mode, Reset, and About.



### Set Channel Offset

The Offset specified for a channel calibrates the 4-20mA signal for the specified input.



To calibrate the transducer or other 4-20mA signal, apply a pressure or weight greater than zero but less than the maximum sensor rating. Pressing up or down on a particular digit will modify only the selected digit. To navigate between digits, press left or right. To save the selected setting, navigate to the far right digit and press right again. The 24V Altos 2<sup>TM</sup> will not allow the user to select a value outside the maximum and minimum values displayed. The default value for this setting is 0.

#### **Set Channel Max**

The Max Pressure Setting specified for a channel configures the maximum pressure rating for the specified pressure transducer or other 4-20mA signal.



Pressing up or down on a particular digit will modify only the selected digit. To navigate between digits, press left or right. To save the selected setting, navigate to the far right digit and press right again. The default value for this setting is 6000 PSI.

**WARNING**: Changing this value to a value that does not match the actual range of the transducer used will result in invalid pressure readings.

### Deadband

The Deadband specified for a channel configures the value that the specified channel units must rise above or fall below the alarm set point to clear the channel alarm (depending on the Input/Alarm Condition).



Figure 31

Pressing up or down on a particular digit will modify only the selected digit. To navigate between digits, press left or right. To save the selected setting, navigate to the far right digit and press right again. The 24V Altos 2<sup>TM</sup> will not allow the user to select a value outside the maximum and minimum values displayed. The default value for this setting is 15 PSI.

#### Audible Mode

Audible Mode provides instructions on how to change the audible mode. Default is ON.



Figure 32

**WARNING**: If audible mode is enabled, each navigational button press results in a chirping sound. If audible mode is disabled the speaker is completely silent.

#### **Power Save Mode**

Power Save Mode, when enabled, turns off the LCD screen after fifteen minutes of inactivity. (When the screen is off the unit will still alarm as normal.) Pressing any button on the front cover will wake the unit up when in power save. Default Mode is OFF.



### **Keypad Lockout**

Keypad Lockout provides instructions for changing the Keypad Lockout mode. Default Mode is OFF.



#### Contrast

Contrast adjustment allows the screen contrast to be adjusted on the 24V Altos 2<sup>™</sup> alarm display. Pressing the up or down buttons will increase or decrease the contrast ratio of the screen. The default factory value is 45. The value can be adjusted between 30 (the lightest) and 58 (the darkest). To save the selected ratio, press the right button.

Max	Value	=	100	
Min	Value	=	0	
	Ø!	50		

Figure 35

## **Test Mode**

Test Mode provides instructions for enabling Test Mode. Test Mode toggles all LED's, speakers and relays as well as displays the 24V Altos logo to test proper operation of the unit. When Test Mode completes ten iterations, the unit returns to the status screen.



#### Reset

Activating Reset restores all parameters to the factory default state and resets the device.

Figure 38



## About

The about screen displays the system part number as well as the installed software version.



Figure 38

# TROUBLESHOOTING

Symptom	Possible Cause	Possible Solution
No display or status lights.	<ul> <li>No power to the system.</li> <li>Check that the power source is live.</li> <li>Power connections came loose from electronic control board.</li> </ul>	<ul> <li>Restore power.</li> <li>Restore power connections to electronic control board</li> <li>Replace electronic control board.</li> </ul>
The pressure readings are incorrect on the system display.	<ul> <li>Transducer is not properly calibrated</li> <li>Transducer connection came loose from the electronic control board</li> <li>Transducer cable is damaged</li> <li>Transducer is not working properly</li> </ul>	<ul> <li>Recalibrate the transducer using the Ch Offset option under the System menu</li> <li>Restore transducer connections to electronic control board</li> <li>Replace transducer cable</li> <li>Replace transducer</li> <li>Replace electronic control board</li> </ul>
There pressure switch status is not displaying properly	<ul><li>Pressure switch connection came loose</li><li>Pressure switch is damaged</li></ul>	<ul><li>Restore pressure switch connections</li><li>Replace pressure switch</li><li>Replace electronic control board</li></ul>
Output relays not functioning	<ul> <li>Remote monitoring system is not powered.</li> <li>Wiring between the 24V Altos 2<sup>TM</sup> output relays and the remote monitoring system is not correct.</li> </ul>	<ul> <li>Check that the remote system is powered on</li> <li>Check wiring between 24V Altos 2<sup>TM</sup> output relays and remote monitoring system.</li> </ul>

## WARRANTY INFORMATION

This equipment is sold by CONTROLS CORPORATION OF AMERICA under the warranties set forth in the following paragraphs. Such warranties are extended only with respect to the purchase of this equipment directly from CONTROLS CORPORATION OF AMERICA or its Authorized Distributors as new merchandise and are extended to the first Buyer thereof other than for the purpose of resale.

For a period of one (1) year from the date of original delivery (90 days in corrosive service) to Buyer or to Buyer's order, this equipment is warrantied to be free from functional defects in materials and workmanship and to conform to the description of this equipment contained in this manual and any accompanying labels and/or inserts, provided that the same is properly operated under conditions of normal use and that regular periodic maintenance and service is performed or replacements made in accordance with the instructions provided. The foregoing warranties shall not apply if the equipment has been repaired: other than by CONTROLS CORPORATION OF AMERICA or a designated service facility in accordance with written instructions provided by CONTROLS CORPORATION OF AMERICA; or altered by anyone other than CONTROLS CORPORATION OF AMERICA; or if the equipment has been damaged or does not function due to improper installation, improper supply of required utilities, accident, abuse, misuse, natural disaster, insufficient or excessive electrical supply, abnormal mechanical or environmental conditions, or debris or particles in the gas or liquid source of supply.

CONTROLS CORPORATION OF AMERICA's sole and exclusive obligation and Buyer's sole and exclusive remedy under the above warranties is limited to repairing using new or reconditioned parts or replacing, free of charge except for labor if permanently installed for the continuous supply of gas by other than a technician certified by CONTROLS CORPORATION OF AMERICA specifically to do so, at CONTROLS CORPORATION OF AMERICA's option, the equipment or part, which is either (1) reported to its Authorized Distributor from whom purchased, and which if so advised, is returned with a statement of the observed deficiency, and proof of purchase of equipment or part not later than seven (7) days after the expiration date of the applicable warranty, to the nearest designated service facility during normal business hours, transportation charges prepaid, and which upon examination, is found not to comply with the above warranties with return trip transportation charges for the equipment or part paid by Buyer or (2) in the case of designated equipment permanently installed for the continuous supply of gas, reported to an Authorized Service Center with proof of initial installation no later than seven (7) days after the expiration date of compliance with the above warranties by technician certified by CONTROLS CORPORATION OF AMERICA, and which is determined by CONTROLS CORPORATION of AMERICA sole on said evaluation to be non-compliant.

#### CONTROLS CORPORATION OF AMERICA SHALL NOT BE OTHERWISE LIABLE FOR ANY DAMAGES INCLUDING BUT NOT LIMITED TO: INCIDENTAL DAMAGES, CONSEQUENTIAL DAMAGES, OR SPECIAL DAMAGES, WHETHER SUCH DAMAGES RESULT FROM NEGLIGENCE, BREACH OF WARRANTY OR OTHERWISE.

THERE ARE NO EXPRESS OR IMPLIED WARRANTIES WHICH EXTEND BEYOND THE WARRANTIES HEREINABOVE SET FORTH. CONTROLS CORPORATION OF AMERICA MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE EQUIPMENT OR PARTS THEREOF.

## **CE** Declaration of Conformity for CE Approved Models

CE Approved models of the CONCOA 24V Altos 2<sup>™</sup> remote alarm will have the "CE" mark on the product nameplate. They are covered by the following CE Declaration of Conformity:



Controls Corporation of America 1501 Harpers Road Virginia Beach, VA. 23454

#### CE DECLARATION OF CONFORMITY In accordance with ISO/IEC 17050

The <u>Altos 2 System Monitor</u> is compliant with the CE directives and standards listed below:

#### **Directives:**

- Electromagnetic Compatibility (89/336/EC)
- Low-Voltage (2006/95/EC)
- RoHS (2002/95/EC)

#### Standards:

- EMC: EN61000-6-2:2001
- EMC: EN61000-6-4:2001
- Safety: EN 61010-1

UALITY MANAGER

Form: QA-170

ADI 0025-24V-J



Certified ISO 9001

## **Certified ISO 9001**

Controls Corporation of America 1501 Harpers Road Virginia Beach, VA 23454 Telephone 1-800-225-0473 or 757-422-8330 • Fax 757-422-3125

www.concoa.com